



## Applent Instruments Inc.

Dangnan Industrial Park, Tianning District, Changzhou

City, Jiangsu Province, China [213014]

Tel: 0519-88805550 / 89966117/89966227/89966337

Fax: 0519-89966550

<http://www.applent.com>

Sales Email: [sales@applent.com](mailto:sales@applent.com)

Tech Email: [tech@applent.com](mailto:tech@applent.com)

©2005-2012 Applent Instruments, Inc.

Rev.A1

## Safety Summary



Warning



Dangerous :

The following general safety precautions must be observed during all phases of operation, service, and repair of this instrument. Failure to comply with these precautions or with specific WARNINGS elsewhere in this manual may impair the protection provided by the equipment. In addition it violates safety standards of design, manufacture, and intended use of the instrument.

Disclaimer

---

The Applent Instruments assumes no liability for the customer's failure to comply with these requirements.

---

Ground  
The Instrument

To avoid electric shock hazard, the instrument chassis and cabinet must be connected to a safety earth ground by the supplied power cable with earth blade.

DO NOT  
Operate In An Explosive  
Atmosphere

Do not operate the instrument in the presence of inflammable gasses or fumes. Operation of any electrical instrument in such an environment constitutes a definite safety hazard.

Keep away  
from live circuit

Operating personnel must not remove instrument covers. Component replacement and internal adjustments must be made by qualified maintenance personnel. Do not replace components with the power cable connected. Under certain conditions, dangerous voltages may exist even with the power cable removed. To avoid injuries, always disconnect power and discharge circuits before touching them.

Operations not included in  
the manual are forbidden

The protection measurements will be failure while beyond the scope.



Warning: TO AVOIDE INSTRUMENT DAMAGED, PLEASE DO NOT PUT DC VOLT OR CURRENT IN THE TESR TERMINAL  
MAKE SURE THE CAPACITOR IS DISCHARGED BEFORE TESTING

Safety Sign:



Provide double insulation or reinforced insulation protection

Waste Electrical and Electronic Equipment (WEEE) order 2002/96/EC



Do not leave it in the trash can

## CERTIFICATION, LIMITED & LIMITATION OF LIABILITY

**Applent Instruments, Inc.** (shortened form **Applent**) certifies that this product met its published specifications at the time of shipment from the factory. Applent further certifies that its calibration measurements are traceable to the People's Republic of China National Institute of Standards and Technology, to the extent allowed by the Institution's calibration facility or by the calibration facilities of other International Standards Organization members.

This Applent instrument product is warranted against defects in material and workmanship for a period corresponding to the individual warranty periods of its component products. **The warranty period is 1 year and begins on the date of shipment.** During the warranty period, Applent will, at its option, either repair or replace products that prove to be defective. This warranty extends only to the original buyer or end-user customer of a Applent authorized reseller, and does not apply to fuses, disposable batteries or to any product which, in Applent's opinion, has been misused, altered, neglected or damaged by accident or abnormal conditions of operation or handling.

For warranty service or repair, this product must be returned to a service facility designated by Applent. The buyer shall prepay shipping charges to Applent and the Buyer shall pay all shipping charges, duties, and taxes for products returned to Applent from another country.

Applent warrants that its software and firmware designated by Applent for use with an instrument will execute its programming instruction when properly installed on that instrument. Applent does not warrant that the operation of the instrument, or software, or firmware, will be uninterrupted or error free.

The foregoing warranty shall not apply to defects resulting from improper or inadequate maintenance by the Buyer, Buyer-supplied software or interfacing, unauthorized modification or misuse, operation outside the environmental specifications for the product, or improper site preparation or maintenance.

THIS WARRANTY IS BUYER'S SOLE AND EXCLUSIVE REMEDY AND IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. APPLMENT SHALL NOT BE LIABLE FOR ANY SPECIAL, INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES OR LOSSES, INCLUDING LOSS OF DATA, WHETHER ARISING FROM BREACH OF WARRANTY OR BASED ON CONTRACT, TORT, RELIANCE OR ANY OTHER THEORY.


People's Republic of China  
Jiangsu Province  
Changzhou Applent Instruments Inc.  
Oct. 2009  
Rev.A1

## Contents

Safety Summary .....	2
CERTIFICATION, LIMITED & LIMITATION OF LIABILITY .....	3
Contents .....	4
1. Installation and Setup Wizard .....	6
1.1 Packing List .....	6
1.2 Power Supply .....	6
1.3 Operation Environment .....	6
1.4 Cleaning .....	7
1.5 Replace Battery .....	7
1.6 Adjusting Tilt Stand .....	7
2. Overview .....	9
2.1 Overview .....	9
2.2 Main Specification .....	9
2.3 Main Function .....	9
2.3.1 FUNCTION .....	9
2.3.2 Sorting Setting .....	10
2.3.3 Correction Function .....	10
2.3.4 System Setup .....	10
2.3.5 Interface .....	10
3. Startup .....	11
3.1 Front Panel Summary .....	11
3.2 LCD Screen .....	12
3.3 Interface .....	13
3.4 Extern power and Battery .....	13
3.4.1 Charge Li Battery .....	13
3.5 Power up .....	14
3.6 Connection of the Thermocouple .....	14
4. [MEAS] Page .....	15
4.1 <MEAS DISPLAY> .....	15
4.1.1 CHAN <b>[01]</b> .....	16
5. [SETUP] Page .....	17
5.1 <Setup> Page .....	17
5.1.1 [MODEL] Setting .....	17
5.1.2 [UNIT] Setting .....	18
5.1.3 [RATE] Setting .....	18
5.1.4 [BEEP] setting .....	18
5.1.5 [HIGH] setting .....	18
5.1.6 [LOW] setting .....	19
6. [SYSTEM] Page .....	20
6.1 <SYSTEM CONFIG> page .....	20
6.1.1 [LANGUAGE] .....	20
6.1.2 [FILE] .....	20
6.1.3 [TOUCH PANEL] .....	21
6.1.4 [BRIGHTNESS] .....	22
6.1.5 DIM DISPLAY [DIM] .....	22
6.1.6 AUTO POWER OFF [APO] .....	23
7. Remote Control .....	24
7.1 USB-HID .....	24
7.2 Programming guide .....	24
7.3 Command set .....	25
7.3.1 Command packet .....	25
7.3.2 Notation Conventions and Definitions .....	26
7.3.3 Parameter types .....	27
7.4 Command Reference .....	27
7.4.1 MODEL Subsystem .....	28
7.4.2 BEEP Subsystem .....	28
7.4.3 RATE Subsystem .....	28

7.4.4	UNIT SubSystem .....	28
7.4.5	CHANON SubSystem.....	29
7.4.6	HIGH SubSystem.....	29
7.4.7	LOW SubSystem.....	29
7.4.8	FETC? SubSystem .....	29
7.4.9	SYST System SubSystem .....	30
7.4.10	IDN? Subsystem.....	30
7.4.11	RST Subsystem .....	30
7.4.12	Error Subsystem .....	30
8.Specification		31
8.1	General Specification .....	31
8.2	Dimension.....	32

# 1. Installation and Setup Wizard



---

This chapter provides the following information:

- Packing List
  - Power Requirements
  - Operation Environment
  - Cleaning
  - Replace Battery
  - Adjusting Tilt Stand
- 

---

## 1.1 Packing List

After you receive the instrument, carry it out and check during unpacking according to the following procedure.

Check that the packing box or shock-absorbing material used to package the instrument has not been damaged.

Referring to the packing list, check that all packaged items supplied with the meter have been provided as per the specified optioned.

If damaged or accessories shortage, please contact the sales department or our agent.

---

## 1.2 Power Supply

The Handheld Temperature Meter can only use our configured AC Adapter ATL909 and Li-battery ATL805

AC Adapter

Input Voltage: 90V-260VAC , 49Hz~62Hz

Power: Max 10VA

---



Warning: Other model AC Adapter is forbidden. Only L909 and L805 rechargeable Li-battery can be used.

---

---

## 1.3 Operation Environment

Ensure the operation environment meets the following requirements

Temperature Range: 0°C ~ 55°C ,

Humidity: 23°C, < 70%RH

Altitude: 0~2000m

## 1.4 Cleaning

Do not attempt to clean the internal of AT4202/4204/4208



Warning:


Don't Use Organic Solvents (such as alcohol or gasoline) to clean the Instrument.

Use a dry cloth or a cloth slightly dipped in water to clean the casing.

## 1.5 Replace Battery

Build-in rechargeable Li-battery, battery has been installed in the instruments before leaving factory. Change the battery according to the following steps:

Figure 1-1 Battery Change



1. Use the screwdriver to loosen the screw in the battery cover and remove the cover.
2. Remove the plug on the old battery, plug a new one, main direction of the plug.
3. Put the new battery into the instrument, recover and tighten the screws.

## 1.6 Adjusting Tilt Stand

Two positions are provided: degree 60 and degree 45


Degree 45 can provide a better stability for the instrument

Figure 1-2 Position of Degree 60




Folded up the bottom of the bracket to achieve degree 45 position

Figure 1-3 Position of Degree 45





## 2. Overview



This chapter provides the following information:

- Overview
- Main Specification
- Main Function

### 2.1 Overview

Thank you for purchasing AT4202/4204/4208 Multi-channel Handheld Temperature Meter

The AT4202/4204/4208 adopts high-performance ARM microprocessor control, collects multi-channel temperature data simultaneously. The AT4202/4204/4208 can be compatible with a variety of temperature sensors, fast response, data stability while with the burnout detection function. Also you can separately calibrate the data of each channel. True-color TFT liquid crystal display, keypad and touch screen double control. Use Li- battery supply power and USB communication. Switch in both English and Chinese.

### 2.2 Main Specification

- Graduation: thermocouple J ,K, T, E, S, N, B
- Basic Accuracy:  $0.2\% \pm 1$
- Measurement Range:  $-200.0^{\circ}\text{C} \sim 1800.0^{\circ}\text{C}$  ( change according to different thermocouple type )
- Resolution:  $0.1^{\circ}\text{C}$
- Channel:     4202       2 channels  
                  4204       4 channels  
                  4208       8 channels

### 2.3 Main Function

#### 2.3.1 FUNCTION

1. Comparator Setting
2. Speed Setting
3. Beep Setting
4. Baud Rate Setting
5. Temperature Unit Setting

### 2.3.2 **Sorting Setting**

Build-in sorting data, each temperature data can be set both up limit and low limit

### 2.3.3 **Correction Function**

Each channel data can be corrected by the user.

### 2.3.4 **System Setup**

- Keypad Lock Function
- Switch in Both Chinese and English
- Data File will Be Saved Automatically
- Touch Screen Setup
- Power Saving Mode

### 2.3.5 **Interface**

#### **USB Host Port:**

USB high-speed mode: 48 MHz, USD-HID Protocol

## 3. Startup

This chapter describes:

- Front Panel Summary
- LCD Screen
- Interface
- External power and Battery
- Power up
- Connection of the Thermocouple

### 3.1 Front Panel Summary

Figure 3-1 Front Panel




Table 3-1 Description of the Front Panel

1	TFT-LCD Screen
2	Select Keys
3	[MEAS] Measurement Key——Enter Measurement Page (Page 15:[MEAS] Page)
4	[SYST] System Key ——Enter System Setting Page (Page 20: [SYSTEM] Page)
5	Power On/Off Battery Charging Indicator
6	Sensor access terminal
7	⊛ Background Brightness——30%,50%,70%, 100% Unlock the Keypad Lock
8	[HOLD] NULL
9	[SETUP] Enter Setup (Page 17:[ETUP] page)

## 3.2 LCD Screen

Figure 3-2 LCD Screen




Table 3-2 LCD Screen descriptions

1	The Page Title
2	The white fields are label; the yellow fields are list box.
3	Help and message information
4	Function Area, Use the select keys to select
5	Display the current sensor model
6	Display the current temperature unit
7	Battery Percentage and Keypad Lock Indicators

### 3.3 Interface

Figure 3-3 Interface panel




Table 3-3 Interface panel description

1	Remote Control Interface(USB-HID)
2	Beep
3	Power Adapter Jack(+9VDC)

### 3.4 Extern power and Battery

The Battery can only be charged by Power Adapter ATL909.

While using the external power supply, the power adapter is also charging the battery.


Figure 3-4 Power Adapter



#### 3.4.1 Charge Li Battery

When the battery power is low, you could use the power adapter to charge the battery. The Power key is orange indicating while charging the battery.

Figure 3-5 Charging LED (Orange)



*Attention!* The key is also orange which charges even when the Temperature meter is off previously.)

### 3.5 Power up

Press the Power key softly to start it.

### 3.6 Connection of the Thermocouple

AT4202 having 2 input ports

AT4204 having 4 input ports

AT4208 having 8 input ports

Figure 3-4 Thermocouple Terminals




Table 3-4 Interface brief description

1	“ + ” positive pole of the thermocouple
2	“ - ” negative pole of the thermocouple



Warning: The isolation voltage can't exceed 100V, otherwise it will do harm to the instrument.

## 4. [MEAS] Page

This section includes all measurement result display information.

- <Measure Display> Page

### 4.1 <MEAS DISPLAY>

When pressing the [Meas] key, the <MEAS DISPLAY> page will appear. <MEASURE DISPLAY> page mainly highlights the measurement results, and current sorting results will be displayed in different font and color.

The following measurement controls can be set:

- Channel Setting


Figure 4-1 AT4208 <MEAS DISPLAY> Page

MEASURE DISPLAY		TC-T (°C)	
01:	<b>28.3</b>	02:	<b>28.2</b>
03:	<b>28.4</b>	04:	<b>28.2</b>
05:	<b>28.4</b>	06:	<b>28.2</b>
07:	<b>28.3</b>	08:	<b>28.2</b>
USB Attached.			
SETUP	SYSTEM		

Figure 4-2 AT4204 <MEAS DISPLAY> Page

MEASURE DISPLAY		TC-T (°C)	
01:	<b>27.9</b>	02:	<b>28.0</b>
02:	<b>28.1</b>	02:	<b>27.9</b>
USB Attached.			
SETUP	SYSTEM		

Figure 4-3 AT4202 <MEAS DISPLAY> Page



#### 4.1.1 CHAN 【01】

##### ■ Steps to Set Sensor Model

Step 1	Press [Meas] key to enter <MEASURE DISPLAY> page	
Step 2	Use the cursor keys to select [01] field	
Step 3	Use side soft keys to select	
	Soft key	Function
	OFF	Close the current channel
	ON	Open the current channel

\*The same steps to close or open other channels


##### ■ The steps of setting users' adjustment

Step 1	Press [Meas] key to enter <MEASURE DISPLAY> page	
Step 2	Use the cursor keys to select [01] field	
Step 3	Use side soft keys to select	
	Soft key	Function
	AMEND	Use touch screen to type in
	CLEAR	Delete amend value

\*The same steps to correct other channel values



## 5. [SETUP] Page



This section includes all setup functions

At any time, press [SETUP] to enter <SETUP> page.

- <SETUP> Page


### 5.1 <Setup> Page

In < SETUP> page, the Instrument does not display any results, testing is not in progress.

The setup includes

- MODEL – Chose the type of the thermocouple
- UNIT – Temperature Unit Setting
- RATE – Sampling Rate
- BEEP – Beep Setting
- HIGH – High Limit
- LOW – Low Limit

Figure 5-1 <Setup> Page



#### 5.1.1 [MODEL] Setting

The model set includes: 8 types thermocouple T , K , J , N , E , S , R , B

##### ■ Steps to set the model

Step 1	Press [Setup] key to enter < SETUP > page	
Step 2	Use cursor keys to select [MODEL] field	
Step 3	Use soft key to select	
	Soft Key	Function
	TC-T	Setting the thermocouple T type
	TC-K	Setting the thermocouple K type
	TC-J	Setting the thermocouple J type

	TC-N	Setting the thermocouple N type
	TC-R	Setting the thermocouple R type
	TC-S	Setting the thermocouple S type
	TC-E	Setting the thermocouple E type
	TC-B	Setting the thermocouple B type

### 5.1.2 [UNIT] Setting

Units Includes:(°C),(K),(F)

#### ■ Steps to set beep feature

Step 1	Press [Setup] key to enter < SETUP > page	
Step 2	Use cursor keys to select [UNIT] field	
Step 3	Use soft keys to select	
	<b>Soft Key</b>	<b>Function</b>
	(°C)	Degree Celsius
	(K)	Degree Kelvin
	(F)	Degree Fahrenheit

### 5.1.3 [RATE] Setting

The Rate set include: Slow, Med and Fast

#### ■ Steps to set rate

Step 1	Press [Setup] key to enter < SETUP > page	
Step 2	Use cursor keys to select [RATE] field	
Step 3	Use soft keys to select	
	<b>Soft Key</b>	<b>Function</b>
	SLOW	Set the sampling rate to slow
	MED	Set the sampling rate to med
	FAST	Set the sampling rate to fast

### 5.1.4 [BEEP] setting

The Beep set include: OFF and ON .

#### ■ Steps to Set the Beep:

Step 1	Press [Setup] key to enter < SETUP > page	
Step 2	Use cursor keys to select [UNIT] field	
Step 3	Use soft keys to select	
	<b>Soft Key</b>	<b>Function</b>
	OFF	Turn off the Beep feature
	ON	Turn on the Beep feature

### 5.1.5 [HIGH] setting

#### ■ Steps to set High limit

Step 1	Press [Setup] key to enter < SETUP > page	
Step 2	Use cursor keys to select [1800.0] field	

Step 3	Use soft keys to select	
	Soft Key	Function
	UPPER VALUE	Use touch screen to type in
	RESET	Restore Defaults

### 5.1.6 [LOW] setting

#### ■ Steps to set Low limit

Step 1	Press [Setup] key to enter < SETUP > page	
Step 2	Use cursor keys to select [-200.0] field	
Step 3	Use soft keys to select	
	Soft Key	Function
	UPPER VALUE	Use touch screen to type in
	RESET	Restore Defaults

## 6. [SYSTEM] Page

This section includes all system information.


At any time, press [SYST] key to enter [SYSTEM] page.

### 6.1 <SYSTEM CONFIG> page

Following information can be configured in the <SYSTEM CONFIG> page.

- System date and time configuration [DATE/TIME]
- LANGUAGE
- FILE
- TOUCH PANEL
- BRIGHTNESS
- DIM DISPLAY
- APO – Auto Power Off

Figure 6-1 <SYSTEM SETUP> Page



#### 6.1.1 [LANGUAGE]

You can switch system language in both Chinese and English.

##### ■ Procedure to change language

Step 1	Press [SYST] key to enter <SYSTEM CONFIG> page.	
Step 2	Select [LANGUAGE]	
Step 3	中文 (CHS)	Switch into Chinese
	ENGLISH	Switch into English

#### 6.1.2 [FILE]

##### ■ Procedure of file setting

Step 1	Press [SYST] key to enter <SYSTEM CONFIG> page.	
Step 2	Select [FILE] field	
Step 3	AUTO	All parameters set by user will be saved in system.
	IGNORED	The parameters will be lost after power off
	SAVE NOW	All parameters set by user will be saved in system.

### 6.1.3 [TOUCH PANEL]

#### Tips

The LCR meter can work well without touch panel. But you cannot type number without touch panel. When you need to input numbers, the touch panel will be activated even it is shut down in system setting.


#### ■ Procedure of setting touch panel

Step 1	Press [SYST] key to enter <SYSTEM CONFIG> page.	
Step 2	Select [TOUCH PANEL] field	
Step 3	ENABLE	Enable touch panel
	DISABLE	Disable touch panel
	CALIBRATE	Calibrate touch panel
	RESET	Reset touch panel data

#### ■ Procedure to calibrate touch panel

#### Tips

You will need a screen pen to calibrate touch panel.  
Do not use your finger!

Step 1	Press [SYST] key to enter <SYSTEM CONFIG> page.
Step 2	Select [TOUCH PANEL] soft key
Step 3	Select [CALIBRATE] soft key
Step 4	Use a screen pen to click screen softly to start calibration 
Step 5	Tap the middle of the circle with a pen on Left-Up corner. Then tap the middle of the circle with a pen on the Right-Bottom corner to finish the calibration.
Step 6	Click on the screen softly to exit.

### 6.1.4 [BRIGHTNESS]

Four degrees of brightness 30%, 50%, 70%, 100%

Tips	If powered by external power, the brightness is 100%.
	If powered by battery, the low brightness can make the meter work longer.



Also, press [] to change the brightness.

Figure 6-2 The Brightness key



#### ■ Procedure to change brightness

Step 1	Press [SYST] key to enter <SYSTEM CONFIG> page.	
Step 2	Select [BRIGHTNESS] field.	
Step 3	30%	30% of full brightness
	50%	50% of full brightness
	70%	70% of full brightness
	100%	Full brightness

### 6.1.5 DIM DISPLAY [DIM]

#### ■ Procedure to dim display:

Step 1	Press [SYST] key to enter <SYSTEM CONFIG> page.	
Step 2	Select [DIM DISPLAY]	
Step 3	5 minutes	5 minutes later, brightness becomes 30%
	10 minutes	10 minutes later, brightness becomes 30%
	20 minutes	20 minutes later, brightness becomes 30%
	30 minutes	30 minutes later, brightness becomes 30%
	OFF	Dim display off

Tips:	Timer will be reset when press any keys or touch screen.
-------	--

## 6.1.6 AUTO POWER OFF [APO]

- Procedure of set auto power off:


Step 1	Press [SYST] to enter <SYSTEM CONFIG> page.	
Step 2	Select[APO]	
Step 3	5 minutes	5 minutes later, power off
	10 minutes	10 minutes later, power off
	20 minutes	20 minutes later, power off
	30 minutes	30 minutes later, power off
	OFF	[APO]off

---

Tips:                   Timer will be reset when press any keys or touch screen.

---

## 7. Remote Control



This chapter provides the following information to remotely control the AT4202/4204/4208 via the USB interface.

### 7.1 USB-HID

The USB-Serial Interface allows you to connect AT4202/4204/4208 to a USB port on your PC.

You don't need to install a driver in Windows system.

Figure 7-1 The APPLNET USB logo in windows device manager



### 7.2 Programming guide

The instrument goes along with data communication and acquisition software. You can also go to our website: [www.applnet.com](http://www.applnet.com) to download.

**Tips:** If you want to program the software by yourself, you need to know some basic knowledge about USB and USB-HID. Go to [www.usb.org](http://www.usb.org) to find out more.

Basic API functions:

- `CreateFile(`  
    `devDetail->DevicePath,`  
    `GENERIC_READ | GENERIC_WRITE,`  
    `FILE_SHARE_READ | FILE_SHARE_WRITE,`  
    `NULL,`  
    `OPEN_EXISTING,`  
    `FILE_FLAG_OVERLAPPED,`  
    `NULL);`

Use `CreateFile` to open HID equipment, equipment communication channels can be found through function `SetupDiGetInterfaceDeviceDetail`.

- `ReadFile(`  
    `hDev,`  
    `recvBuffer,`



```

    IN_REPORT_LEN,
    &recvBytes,
    &ol);

```

Use ReadFile to read HID equipment. Report based on the data transferred from IN.

- WriteFile (
 

```

hDev,
reportBuf,
OUT_REPORT_LEN,
&sendBytes,
&ol);

```

WriteFile is used to transfer an output report to HID equipment.

- Communication Parameters

VIP: 0825

PID: 0826

Packet size: 64bits

---

*Tips:* Any problems in programming, please contact our tech department, you can send an email to [tech@applent.com](mailto:tech@applent.com).  
 USB is always available, you don't need to set any parameters.

---

## 7.3 Command set

### 7.3.1 Command packet

Use 64 bits/pack to transfer data; every USB-HID command is 1 pack.

*Tips:* Command packets have a fixed format, the user must follow the format agreed by the instrument of writing, and otherwise it is impossible to establish communication.  
 The command word is case-insensitive.  
 Each command packet contains the first 60 bytes of checksum, fill in the last four bytes.

PC command pack format(a C language-defined pack structure):

```

#define program pack(1)
typedef __packed struct
{
    uint    cSize;    //packet size 4bytes    =60
    char    sHeader[24]; //command 24bytes
    char    sPara[28]; //parameter 28bytes
    uint    nSignature; //signature 4bytes
    uint    nChecksum; //Checksum 4bytes
} TUSB_CMD;
#define program pack()

```

Here,

cSize: 60  
 nSignature: 0x88805550  
 sCmd,sPara: reference at SCPI set  
 nChecksum: 32 checksum

A complete send command pack(from PC) as follows:

cSize: 0x0000003C,  
 sHeader: IDN?  
 sPara: (blank)  
 nSignature: 0x88805550  
 nChecksum: 0x00002BC1

As command pack format and number of bits are fixed, so command words and parameters which are not qualified with the specified number of bytes must be filled hexadecimal. HEX: 0x00.

Table 7-1A complete command pack in Hex format.

0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
00	00	00	40	49	44	4E	3F	00	00	00	00	00	00	00	00
16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31
00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47
00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
48	49	50	51	52	53	54	55	56	57	58	59	60	61	62	63
00	00	00	00	00	00	00	00	88	80	55	50	00	00	2B	C1

Instrument response pack is 64 bytes, which is not sufficient for 0x00 fill out. (Not ASCII “0”)

A response pack (from instrument):

ASCII format: AT4202, REV A1.0, 00000000, Applent Instruments Inc.

To test instrument USB-HID, we have free “Applent HID communication tester” software, you can download from:[www.applent.com](http://www.applent.com)

### 7.3.2 Notation Conventions and Definitions

A definition is not a part of a command, it is just used in interpretation and is not included in transfer.

The following conventions and definitions are used in this chapter to describe USB-HID operation

Table 7-2 Notation Conventions and Definitions

◇	Name of a parameter
[ ]	The content is optional
	Select from several options

### 7.3.3 Parameter types

Parameters may be of four types as follows.

Table 7-3 Available data type

Format		Samples
<NR1>	Integer	100,+100,-100
<NR2>	Rational	1.23,+1.23,-1.23
<NR3>	Floating-point	1.23E4, +1.23E4,-1.23E4,-1.23e-4
<NR4>	Floating-point with magnification	1.23K,1.23N,1.23U (magnification in following Table)

Table 7-4 Magnification

Definition	Suffix
1E18 (EXA)	EX
1E15 (PETA)	PE
1E12 (TERA)	T
1E9 (GIGA)	G
1E6 (MEGA)	MA
1E3 (KILO)	K
1E-3 (MILLI)	M
1E-6 (MICRO)	U
1E-9 (NANO)	N
1E-12 (PICO)	P
1E-15 (PEMTO)	F
1E-18 (ATTO)	A

## 7.4 Command Reference

All commands in this reference are fully explained and listed in the following functional command order.

- MODEL      Model subsystems
- BEEP        Beep subsystem
- RATE        Rate subsystem
- UNIT        Unit subsystem
- CHANON     Chanon subsystem
- HIGH        High subsystem
- LOW         Low subsystem
- FETC?      Fetc? subsystem
- IDN?        Version check subsystem
- RST         Hot start subsystem
- ERR         Error subsystem

7.4.1 **MODEL Subsystem**

## ■ model &lt;tc-t|tc-k|tc-j|tc-n|tc-e|tc-s|tc-r|tc-b&gt;

	To set the model
sHeader	Model
sPara	<tc-t tc-k tc-j tc-n tc-e tc-s tc-r tc-b>

## ■ model?

	To check the current model
sHeader	Model?
sPara	
Response	<tc-t tc-k tc-j tc-n tc-e tc-s tc-r tc-b>

7.4.2 **BEEP Subsystem**

## ■ beep &lt;on|off&gt;

	To set the beep
sHeader	Beep
sPara	<on off>

## ■ beep?

	To check the current beep
sHeader	beep?
sPara	
Response	<on off>

7.4.3 **RATE Subsystem**

## ■ rate &lt;slow|med|fast&gt;

	To set the rate
sHeader	Rate
sPara	<slow med fast>

## ■ rate?

	To check the current rate
sHeader	rate?
sPara	
Response	<slow med fast>

7.4.4 **UNIT SubSystem**

## ■ unit &lt;unit-c|unit-k|unit-f &gt;

	To set the unit
sHeader	Unit
sPara	< unit-c unit-k unit-f >

## ■ unit?

	To check the current unit
sHeader	Unit?

sPara	
Response	< (°C) (K) (F)>

#### 7.4.5 CHANON SubSystem

##### ■ Chanon <integer>

	To set the channel status
sHeader	chanon
sPara	<integer> 8-bit data , each bit representing a channel 0: off 1: Open Example: 11111110 , channel 1 is closed , 2 to 8 channels is open

##### ■ chanon?

	To check the current channel status
sHeader	chanon?
sPara	
Response	<integer>

#### 7.4.6 HIGH SubSystem

##### ■ high <float>

	To set upper limit
sHeader	High
sPara	<float>

##### ■ high?

	To query current upper limit
sHeader	High?
sPara	
Response	<float>

#### 7.4.7 LOW SubSystem

##### ■ low <float>

	To set low limit
sHeader	Low
sPara	<float>

##### ■ low?

	To query current low limit
sHeader	low?
sPara	
Response	<float>

#### 7.4.8 FETC? SubSystem

##### ■ FETC?

	To query test result
sHeader	FETC?


sPara	
Response	<float,float,float,float,float,float,float,> <b>RET&gt;28.0,27.9,28.1&lt;NL&gt;</b>

#### 7.4.9 SYST System SubSystem

- SYST:KEYL <ON | OFF | 1 | 0>

	To lock/unlock keypad and touch screen
sHeader	SYST:KEYL
sPara	<ON   OFF   1   0>

---

*Tips:* When the keypad and screen is locked, press[]to unlock !  
Power key can't be locked

---

#### 7.4.10 IDN? Subsystem

- IDN?

	To check version information
sHeader	IDN?
sPara	
Response	AT4202,REV A1.0,<Serial Number>,Applent Instruments Inc.

#### 7.4.11 RST Subsystem

- RST

	To start in heat
sHeader	RST
sPara	

#### 7.4.12 Error Subsystem

- ERR?

	To check the message sent previously
sHeader	ERR?
sPara	
Response	In the following Table

Table 7-5 The Error Code and message

0, No error
1, Bad command
2, Parameter error
3, Missing parameter
4, Invalid multiplier
5, Numeric data error
6, Value too long
7, Invalid command

## 8. Specification

This chapter describes the specifications and supplemental performance characteristics of the AT4202/4204/4208:

- Specifications
- Dimension

### 8.1 General Specification

The Data is Achieved under the Following Conditions:

- Temperature: 23°C±5°C
- Humidity: ≤65% R.H.
- Warm-up Time: > 60 minutes
- Calibration Time : 12 months

Test Environment:

- Temperature and humidity range: 15°C~35°C, 80% RH or less
- Storage temperature and humidity range: 10°C~40°C, 10~90% RH

Thermocouple Type: T,K,J,N,E,S,R,B  
 Basic Accuracy: 0.2%+1bit  
 Display: 5 digits  
 Test Speed: Fast, Medium, Slow  
 Max Reading: 1800.0°C  
 Min Reading: -200.0°C  
 Beep: ON/OFF  
 Interface: USB-HID  
 Program Language: SCPI  
 Auxiliary Function: Keypad Lock

Model	Temperature Range ( °C )
T-type thermocouple	-150°C ~ 400°C
K-type thermocouple	-100°C ~ 1350°C
J-type thermocouple	-100°C ~ 1200°C
N-type thermocouple	-100°C ~ 1300°C
E-type thermocouple	-100°C ~ 850°C
S-type thermocouple	250°C ~ 1750°C
R-type thermocouple	250°C ~ 1750°C
B-type thermocouple	250°C ~ 1800°C

## 8.2 Dimension

